
YOSHIMASA ASSUMES NO LIABILITY REGARDING THE IMPROPER INSTALLATION OR MISAPPLICATION OF ITS PRODUCTS. IT IS THE INSTALLER'S RESPONSIBILITY TO CHECK FOR PROPER INSTALLATION. UNDER NO CIRCUMSTANCES WILL YOSHIMASA BE LIABLE FOR ANY LABOR CHARGED OR TRAVEL TIME INCURRED INSTALLATION OF ITS PRODUCTS. DAMAGE CAUSED BY IMPROPER INSTALLATION IS THE INSTALLER'S RESPONSIBILITY AND YOSHIMASA ASSUMES NO LIABILITY. THE FOLLOWING INSTRUCTIONS ONLY SET AN OUTLINE FOR PRODUCT INSTALLATION.

### INSTALL A SELF-CONTAINED UNIT



YMSC Series Self-contained (Refrigerated) Sushi Case w/ Condensing Unit built-in LEFT Side of the Unit

Before you install a Self-contained (Refrigerated) Sushi Display Case, please read the Owner's Manual that came with the unit and all Warning Signs attached to the unit body. While reading, pay extra attention to Warranty Issues. Upon fully undersdtanding the unit, including the pathway of AIRFLOW in the Condensing Unit, follow the step-by-step instructions below:

- 1. Locate and prepare counter top Sushi Case install location
- 2.Carefully place the Sushi Case on the counter top
- 3. Give enough space to the condensing unit for unrestricted Air Flow
- 4.Plug in the Power Cord (use a 115/60/1, 15 amp DEDICATED outlet)
- 5.Turn on the Power Switch

## 1. Locate and prepare counter top Sushi Case install location

The counter top should be flat and have wide and long enough room to give the condensing unit of the Sushi Case free flow of air.












Plus carefully locate the place that the unit can avoid any sort of heating appliance such as oven, rice cooker, gas range, fan etc. If they are to be with the unit in the same area, please place the unit at least 6-foot (72-inch) away from them.

# 2. Carefully place the Sushi Case on the counter top

Condensing unit side is much havier than the other side, so be careful when taking it out of the shipping box.

YOSHIMASA ASSUMES NO LIABILITY REGARDING THE IMPROPER INSTALLATION OR MISAPPLICATION OF ITS PRODUCTS. IT IS THE INSTALLER'S RESPONSIBILITY TO CHECK FOR PROPER INSTALLATION. UNDER NO CIRCUMSTANCES WILL YOSHIMASA BE LIABLE FOR ANY LABOR CHARGED OR TRAVEL TIME INCURRED INSTALLATION OF ITS PRODUCTS. DAMAGE CAUSED BY IMPROPER INSTALLATION IS THE INSTALLER'S RESPONSIBILITY AND YOSHIMASA ASSUMES NO LIABILITY. THE FOLLOWING INSTRUCTIONS ONLY SET AN OUTLINE FOR PRODUCT INSTALLATION.


### 3. Give enough space to the condensing unit for unrestricted Air Flow





If the Condensing unit side is to be next to a closed wall, the Airflow OUTLET has to be at least 6-inch away from the wall otherwise the compressor will get serious damage. Blocking airflow is a direct violation of Warranty term and the warranty will be canceled.





Suppose installing two Sushi Cases (one with the Condensing unit on the LEFT, the other with on the RIGHT), we DO NOT recommend that two Condensing units' sides meet together side-to-side on the same counter top because warm air from the OUTLET of the condensing unit will affect each other. It is considered as blocking air flow. In this case, however, we highly recommend that those units be set apart at least 24-inch from each other.





We DO NOT also recommend that two Condensing units' sides cross at a right angle or any acute angle for the same reason explained above. It is considered as blocking air flow. Please put the Sushi Cases apart at least 17-inch from each other.

YOSHIMASA ASSUMES NO LIABILITY REGARDING THE IMPROPER INSTALLATION OR MISAPPLICATION OF ITS PRODUCTS. IT IS THE INSTALLER'S RESPONSIBILITY TO CHECK FOR PROPER INSTALLATION. UNDER NO CIRCUMSTANCES WILL YOSHIMASA BE LIABLE FOR ANY LABOR CHARGED OR TRAVEL TIME INCURRED INSTALLATION OF ITS PRODUCTS. DAMAGE CAUSED BY IMPROPER INSTALLATION IS THE INSTALLER'S RESPONSIBILITY AND YOSHIMASA ASSUMES NO LIABILITY. THE FOLLOWING INSTRUCTIONS ONLY SET AN OUTLINE FOR PRODUCT INSTALLATION.

### 3. Give enough space to the condensing unit for unrestricted Air Flow





For a better looking if you apply custom-made Joint Box between two Sushi Cases where two Condensing units' sides cross, make big enough room (each side of Joint Box should be at least 12" long) for OUTLET Airflow otherwise it is considered as blocking air flow. Make several big holes on the top of the Joint Box would be a good idea.





DO NOT block the INLET and OUTLET Airflow pathway by putting things such as menu, decorative stuff, food cans, ingredient containers, personal belongings, etc. Keep the air pathway clear at all times otherwise it is considered as blocking air flow.

## 4. Plug in the Power Cord (use a 115/60/1, 15 amp DEDICATED outlet)













Use a 115VAC, 60Hz, 1 phase, 15 amp DEDICATED outlet, but DO NOT share or overload multi-way outlet sockets in the same circuit for any other electric appliance. Sharing power outlet in the same circuit is a direct violation of Warranty term and the warranty will be canceled. Also we DO NOT recommend use any type of extension power strip.

YOSHIMASA ASSUMES NO LIABILITY REGARDING THE IMPROPER INSTALLATION OR MISAPPLICATION OF ITS PRODUCTS. IT IS THE INSTALLER'S RESPONSIBILITY TO CHECK FOR PROPER INSTALLATION. UNDER NO CIRCUMSTANCES WILL YOSHIMASA BE LIABLE FOR ANY LABOR CHARGED OR TRAVEL TIME INCURRED INSTALLATION OF ITS PRODUCTS. DAMAGE CAUSED BY IMPROPER INSTALLATION IS THE INSTALLER'S RESPONSIBILITY AND YOSHIMASA ASSUMES NO LIABILITY. THE FOLLOWING INSTRUCTIONS ONLY SET AN OUTLINE FOR PRODUCT INSTALLATION.

### 5. Turn on the Power Switch





For more information please contact Yoshimasa Canada: PureRange Ent. Ltd.

1560 Booth Avenue, Coquitlam, BC, Canada, V3K 1B9

Order Telephone: (+1)778.397.7873 Toll Free: (+1) 888.997.1560 E-Mail: info@purerange.com

